MASON INDUSTRIES, Inc.

Manufacturers of Vibration Control Products 350 Rabro Drive Hauppauge, NY 11788 631/348-0282 FAX 631/348-0279 Info@Mason-Ind.com www.Mason-Ind.com

2101 W. Crescent Ave., Suite D Anaheim, CA 92801 714/535-2727 FAX 714/535-5738 Info@MasonAnaheim.com

CUSTOMER. CUSTOMER P.O. _ MASON M.I. DWG. NO.,

JOB NAME

All Directional Seismic Snubber Sizes 250-2000

Z-1225 - 250 thru 2000 1/2" (13) Clearance	Equipment Base
Equipment Base Anchor Bolt (by Mason)	Steel Bushing All Directional Neoprene Bushing
	Snubber Bolt & Washer D - Bolt Hole Diameter AB -Anchor Bolt Diameter (bolts by others)
G F C T	B * If Snubber Angles are to be secured by welding, they must be located over Beams or Steel Sole Plates trype Z-1225 1G ALL-DIRECTIONAL LOAD

OSHPD OPA-0196 6925 3141 2000 🖧 5250 1000 1625 7625 2750 1250 250 Ź80 127 3100 5000 5100 HORIZONTAL

Horizontal, Vertical and 45° plotted Ratings are California OSHPD approved values having the OSHPD Anchorage Preapproval No.OPA-0196. Testing and calculations were performed to meet OSHPD criteria.

To use approved OSHPD rated load curves: 1) Calculate Vertical & Horizontal Forces on mounting including translations and overturning moments. 2) Plot Horizontal Load vs Vertical Load. The point must fall within the area below the OSHPD curve.

AD RATINGS and DIMENSIONS

	Size	1G All Directional Load Ratings	s A	AB	В	С	D	E	F	G	Т	Equipment Base Anchor Bolt Size & Length
U.S.A. or British (lbs. & Inches)	250 500 1000 2000	250 lbs 500 lbs 1000 lbs 2000 lbs	2 23/4 3 5	1/2 1/2 5/8 3/4	5 7 8 12	1 1/2 2 2 1/2 3	5/8 5/8 3/4 7/8	3 4 5 6		3 1/2 4 5 6	1/4 1/4 3/8 1/2	1/2" - 13UNC - 4" 5/8" - 11UNC - 6" 3/4" - 10UNC - 6" 3/4" - 10UNC - 6"
Metric (kgs. & mm)	250 500 1000 2000	113 kgs 227 kgs 454 kgs 907 kgs	51 70 76 127	13 13 16 19	127 178 203 305	38 51 64 76	16 16 19 22	76 102 127 152	54 60 64 76	89 102 127 152	6 6 10 13	1/2" - 13UNC - 4" 5/8" - 11UNC - 6" 3/4" - 10UNC - 6" 3/4" - 10UNC - 6"

NOTES:

OPA-0196

1. Neoprene Bushings are 1/4" (6mm) 6. Distance from Base Anchor Bolt center- c. Pass Restraining Angle over steel thick throughout.

Bill Staehlin (916) 654-3362

January 6, 2003

APPROVED California Office of Statewide Health Planning and Development

FIXED EQUIPMENT ANCHORAGE

- 2. Operating clearances are 1/4" (6mm).
- 3. Set Base Anchors to protrude 3/4" (19mm) from face to face.
- 4. A continuous rod, threaded on each end 8. and protruding 3/4" (19mm) from both the faces of the base may be used to secure the threaded steel bushings in lieu of the individual Base Anchor Bolts.
- 5. Normal clearance between base & floor is 1" (25mm).
- line to bottom of base is F minus 1"
- 7. When 2" clearance between base and floor is specified, use 1" spacer plate under snubber angle.
- Earthquake restraining angles are to be installed after equipment is in operation assure design clearances maintained as follows:
- a. Remove snubber bolt and washer.
- b. Screw steel bushing on Base Anchor Bolt protrusion.
- bushing so it is centered horizontally.
- d. Raise or lower base with spring adjustments or shim Restraining Angle so steel bushing is centered vertically.
- e. Set Restraining Angle so inside vertical face is 1/2" (13mm) clear of base and parallel to it.
- f. Mark and set AB anchor bolts or weld angle in position.
- g. Replace snubber bolt and washer and tighten in position.

TYPE	QTY.	TAG

DWN: CHKD: DATE: DWG. No. Certification Form S-101 01/2011



MASON INDUSTRIES, Inc.

350 Rabro Drive Hauppauge, NY 11788 631/348-0282 FAX 631/348-0279 Info@Mason-Ind.com

Manufacturers of Vibration Control Products 2101 W. Crescent Ave., Suite D Anaheim, CA 92801 714/535-2727 FAX 714/535-5738 Info@MasonAnaheim.com www.Mason-Ind.com

JOB NAME
CUSTOMER
CUSTOMER P.O.
MASON M.I.
DWG. NO

Seismic Snubber

Sizes 3000-5000

Z-1225 3000 thru 5000 **Equipment Base** Steel Bushing 1/2" (13 mm) Clearance All Directional **Equipment Base** Neoprene Bushing Anchor Bolt (by Mason) Subber Bolt & Washer D - Bolt Hole Diameter AB - Anchor Bolt Diameter (Bolts by others) 1/4" (6mm) Gusset * If Snubber Angles are to be secured by welding, they must be located over Beams or Steel Sole Plates

TYPE Z-1225 1G ALL-DIRECTIONAL LOAD RATINGS and DIMENSIONS

		Size	1G All Directional Load Ratings	Α	AB	В	С	D	E	F	G	Н	Т	Equipment Base Anchor Bolt Size & Length
U.S.A. or British	`	3000 5000	3000 lbs 5000 lbs	4 3/4 6	3/4	12 15	5	7/8 1 1/8	10 12	3 1/4	6 3/8 6 3/8		3/8 3/8	7/8" - 9UNC - 6" 1" - 8UNC - 6"
DIIUSII	Inches)	3000	200 ms	O	ı	15	O	1 1/0	12	3 1/2	0 4/0	4 4/4	3/0	1 -80NC-6
Metric	(kgs. &	3000	1361 kgs	121	19	305	127	22	254	83	162	95	10	7/8" - 9UNC - 6"
	mm)	5000	2268 kgs	152	25	381	152	29	305	89	162	121	10	1"-8UNC-6"

NOTES:

- 1. Neoprene Bushings are 1/4" (6mm) 6. Distance from Base Anchor Bolt centerthick throughout.
- Operating clearances are 1/4" (6mm).
- 3. Set Base Anchors to protrude 3/4" (19mm) from face to face.
- and protruding 3/4" (19mm) from both the faces of the base may be used to secure the threaded steel bushings in lieu of the individual Base Anchor Bolts.
- 5. Normal clearance between base & floor is 1" (25mm).
- line to bottom of base is F minus 1".
- When 2" clearance between base and floor is specified, use 1" spacer plate under snubber angle.
- 4. A continuous rod, threaded on each end 8. Earthquake restraining angles are to be installed after equipment is in operation assure design clearances maintained as follows:
 - a. Remove snubber bolt and washer.
 - b. Screw steel bushing on Base Anchor Bolt protrusion.
- c. Pass Restraining Angle over steel bushing so it is centered horizontally.
- d. Raise or lower base with spring adjustments or shim Restraining Angle so steel bushing is centered vertically.
- e. Set Restraining Angle so inside vertical face is 1/2" (13mm) clear of base and parallel to it.
- *f. Mark and set AB anchor bolts or weld angle in position.
- g. Replace snubber bolt and washer and tighten in position.

TYPE	QTY.	TAG

Certification Form S-113 04/2009	DWN:	CHKD:	DATE:	DWG. No.